



NOTES:

1. ALL TEMP COLD PATCHING TO BE 1-1/2" MINIMUM DEPTH.
2. KEEP TRENCH BOTTOM COMPACTED WITH UNIFORM GRADE. NO TEMPORARY SUPPORTS, I.E. BLOCKS, WILL BE ALLOWED TO SUPPORT PIPE. TRENCH BOTTOM SHALL BE TO GRADE PRIOR TO PIPE INSTALLATION.
3. CDF MUST CURE FOR A MINIMUM OF 48 HOURS PRIOR TO PAVING.
4. TRENCH SHALL BE PLATED UNTIL CDF IS CURED FOR TEMP OR PERMANENT PATCH.
5. PLATE TO BE SECURED BY METHOD APPROVED BY ENGINEER.



ARTERIAL TRENCH RESTORATION

STANDARD PLAN: ST - 010		CITY ENGINEER APPROVAL:	
DATE: FEB. 2007		Longview: C.B.	
		Kelso: S.Z.	